For 2 suspensions

OSEM PCB Fabrication & Assembly

Scope of supply and specifications

a. PCB Fabrication

- i. Quantity for each PCB board
 - 1. OSEM Mainboard Qty: 8 Nos
 - 2. OSEM Daughterboard Qty: 8 Nos
 - 3. SEI board Qty 8 Nos

ii. Gerber File

The PCB Fabrication file (Gerber file) is provided by IUCAA for the OSEM Mainboard, OSEM daughterboard and SEI board. The vendor needs to fabricate the PCBs.

iii. Board details

- 1. Each PCB has 2 layers. However, all the components are placed only on the top layer.
- 2. The thickness of the PCB should be 1.6mm.
- 3. PCB material: FR4
- 4. Surface Finish: Electroless nickel immersion gold (ENIG)
- Solder Mask: Green
- 6. Copper thickness: 35um
- iv. Bare board testing (BBT) needs to be done.

b. Assembly of Components on PCB

i. Bill of Materials

IUCAA will provide the BOM. The vendor must purchase all the components per BOM and include their cost in the order. The pdf file of the silk screen with pad enabled for both layers will be provided by IUCAA.

ii. Certificate of Conformance (COC)

All components need to be procured from manufacturers, authorized distributors or standard suppliers such as digikey, element14, mouser. We would like to have a Certificate of Conformance (COC) for all the components.

iii. Soldering

1. Soldering requirement

Most of the components are SMD packages except connectors and transistors. Few ICs are sensitive to soldering temperature. So, the soldering temperature of any of the SMD components should not exceed its specified soldering temperature as per the datasheet.

2. ESD requirement

Electrostatic charges as high as 4000 V readily accumulate on the human body and test equipment and can discharge without detection. Although some of the components feature proprietary ESD protection circuitry, permanent damage may occur on devices subjected to high-energy electrostatic discharges. Therefore, proper ESD precautions are recommended to avoid performance degradation or loss of functionality.

c. Cable Fabrication

- i. PCB_Sus Cable: Qty: 4
 - 1. 2 X 14 pin FRC to DB25 female
 - 2. Cable pinout details as per page 3 of the Cable Pinout Diagrams.
 - 3. The bulkhead DB25 and FRC connector have to be crimpable.

ii. PCB DAQ Cable: Qty: 4

- 1. 2 X 14 pin FRC to DB25 female
- 2. Cable pinout details as per page 3 of the Cable Pinout Diagrams.
- 3. The bulkhead DB25 and FRC connector have to be crimpable.

iii. SIM9B2 to Suspension Cable: Qty: 6

- DSub25 male to DSub25 female twisted pair shielded cables, 3 meters length
- Cable shielding needs to be connected to the connector body.
- 3. Cable pinout details as per page 4 of the Cable Pinout Diagrams.

iv. SIM9B2 to Adapter board cable: Qty: 6

- DSub25 male to DSub25 female twisted pair shielded cables, 3 meters length
- 2. Cable shielding needs to be connected to the connector body.
- 3. Cable pinout details as per page 4 of the Cable Pinout Diagrams.

v. Sus to OSEM Cable: Qty 5

1. DB25 to RJ45 CAT8 cables.

2. Cable pinout details as per page 5 of the Cable Pinout Diagrams.

vi. PCB SEI SIM9B2 Cable: Qty: 8

- 1. 14-pin FRC to DB15 female
- 2. Cable pinout details as per page 6 of the Cable Pinout Diagrams.
- 3. The bulkhead DB15 and FRC connector have to be crimpable.

vii. SIM9B2 to SEI sensor: Qty: 8

- DSub15 male to DSub15 female twisted pair shielded cables, 3 meters length
- 2. Cable shielding needs to be connected to the connector body.
- 3. Cable pinout details as per page 7 of the Cable Pinout Diagrams.

viii. SEI Sensor to OSEM Cable: Qty: 8


- 1. DB15 male to RJ45 male cables.
- 2. Cable pinout details as per page 8 of the Cable Pinout Diagrams.

Note:


- All Dsub Connectors should be with metal back shells.
- Heat shrink tube(HST) needs to be put in and the connectivity test should be performed.

d. Quality Assurance Checks


- i. Manual/Visual Inspection of assembled boards to ensure soldering quality.
- ii. The cable connectivity resistance value should be less than 0.5 ohm (19.5.1).
- iii. Functionality tests of the assembled boards and cables will be done by the End user.
- iv. Any manufacturing defect discovered within 6 months of supply needs to be reworked by the vendor.
- v. Each cable shall be 100% electrically tested per IPC/WHMA-A-620C, sections 19.4 and 19.5.
- vi. Insulation resistance shall be more than 100 MOhms when measured at 100 Vdc (19.5.4)




OSEM Main Board




OSEM Daughter Board





Different sections of the circuit on the OSEM Main PCB




SEI Board








Overall Cabling Scheme




Cables Inside SIM9B2 box



FRC Female Connectors on PCBs


DB25 female Connectors on Front Panel of SIM9B2

Pinout diagram of the items (i) & (ii) in Cable Fabrication section




Pinout diagram for Cables:


- iii) SIM9B2 to Adapter board
- iv) SIM9B2 to Suspension




Pinout diagram for Cable: (v)Sus to OSEM Cable



Pinout diagram for Cable: (vi)PCB_SEI to SIM9B2



Pinout diagram for Cable vii) SIM9B2 to SEI Sensor



Pinout diagram for Cable: (viii)SEI sensor to OSEM

